



Energy, everywhere.

CAPACITY UTILIZATION (CU) CONTRACTS & ALLOCATION



CU CONTRACTS & ALLOCATION - IMPORTANT INFORMATION

- Link: [Capacity Utilization \(CU\)](#)
- Only users registered with GCA (with active TSO assignment on PRISMA) have access to **CU Contracts & Allocation**
- Upon user deactivation, user account will be automatically locked
- For questions regarding **CU Contracts & Allocation** module, please contact sales@gasconnect.at
- For questions regarding CU Nomination & Configuration module, please contact commercial.dispatching@gasconnect.at



WHAT CAN BE DONE IN CU CONTRACTS & ALLOCATION?

In **CU Contracts & Allocation**, you can perform the following actions:

- Administrate the GCA registration process
- Manage capacity allocation
- Submit online inquiries for MAB capacities
- Receive quotations and contracts online for MAB capacities
- Perform First-Come-First-Serve (Fall Back) bookings
- Surrender capacity online
- Change within day allocations for long-term contracts
- Receive customised information on maintenance activities
- Customise newsletter according to your interests
- Create capacity conversion requests
- Receive current news



Next upcoming planned maintenance: [1]. For details expand here.


Current News «1»

Dashboard



Quick allocation
Manage capacity allocations of your within-day and day-ahead contracts.

0/0



Long-term allocation
Manage capacity allocations of your monthly, quarterly and yearly contracts.

21




Contract overview
Check all your running contracts.

21



Fallback booking
Book capacity on a "first come, first served" basis in case of a PRISMA outage.

0



Surrendered contracts
Review your surrendered contract's auction results.

11



MAB Booking
Review your MAB bookings.

0

LOGIN DATA



The screenshot shows the PRISMA login interface. At the top left is the PRISMA logo, a green stylized 'P' inside a circle, followed by the text 'Capacity Utilization'. Below the logo are three input fields: the first contains the email address 'PRISMA_email@company.com', the second contains masked characters '.....', and the third contains the password '12345'. Below the password field is a link 'How can I get an authentication code?'. Below that is a link 'Forgot or renew my authentication code secret key'. At the bottom left is a link 'Forgot your password?' which is highlighted with a red box and an arrow pointing to the right. At the bottom center is a green 'Login' button.

Remember: If you change your e-mail address on PRISMA, your CU login will change automatically!

Your LOGIN is the e-mail address with which you registered on PRISMA

You can set your password by clicking „Forgot your password?“

AUTHENTICATION CODE SECRET KEY & AUTHENTICATION CODE

Capacity Utilization

PRISMA_email@company.com

Authentication code

How can I get an authentication code?

Forgot or renew my authentication code secret key

Forgot your password?

Login

To ensure system security, you are required to enter an **authentication code**.

Need help? Click below for a detailed instruction on [how to I get an authentication code](#)

Generate an authentication code in the TOTP application on your devices

To log in for the first time, create your secret key, then install TOTP generator application